



ELECTRIC MACHINES – EUROLAB – 0.3 kW



CAPACITOR UNIT



DL 30135

Set of capacitors for either starting or steady-state running of the split-phase motor.

RESISTOR UNIT



DL 30135R

Auxiliary resistor for the starting of the split-phase motor.


INDUCTOR UNIT



DL 30135L

Auxiliary inductor for the starting of the split-phase motor.

PARALLEL BOARD



DL 1030

Rotating light synchronoscope, complete with the accessories that are required to perform the parallel connection between synchronous generators or between the alternator and the mains

FLYWHEEL



DL 1041

Used in the deceleration tests on rotating machines for the calculation of the mechanical iron and copper losses at different excitations.